



1. With the enclosed 3mm T handle wrench, remove all original screws and be sure to fully seat the T handle in to the screw head to prevent stripping of the screw.



2. Keep the original foot and screws together. Store in a safe place.



3. Take the new KES replacement foot with the provided screws and attach to the lens. **Do not over tighten the screws as this could cause damage to the lens.**



4. Periodically check that all 4 screws are fully tightened.