

# QRLB-T

## Side Arm Adjustment



**1.** Start by removing the 5/32 hex wrench from the quick release body.



**2.** **Slightly and evenly** loosen the two button head screws in the bottom of the bracket.

**3.** With the screws loosened, this now allows you to make any side arm adjustment that is needed to fit your camera set up.



**4.** After you have positioned your side arm where desired, **evenly tighten** the two button head screws

**5.** Reinsert the 5/32 hex wrench back into the quick release body for storage.

