

# Tripod Head Quick Release System

TQR-1S  
TQR-2L



**1.** Screw the tripod quick release assembly onto the tripod.



**2.** Take enclosed 1/8 hex wrench and tighten the quick release locking screw. The screw is found in the center hole of the sticker pocket.



**4.** Now take the tripod head quick release plate and the enclosed 3/8 button head screw then fully tighten down on your tripod head.



**5.** Now take the enclosed 1/4 -20 cone point lock screw and place in your desired mounting hole.

(The large mounting plate offers 4 threaded holes to choose from)  
(the small mounting plate offers 2 threaded holes to choose from)



**6.** This is what your completed assembly should look like.



www.kirkphoto.com  
800.626.5074 • 260.665.3670  
333 Hoosier Drive,  
Angola, IN 46703-9336