



1. Install L-bracket to the base of the camera using the enclosed 5/32 hex wrench. Make sure the L-bracket is tight against the left side of the camera. Do not fully tighten the screw at this time (**you will tighten this in step #3**).



3. Rotate the strap tab over the top of the camera strap loop and retighten the cap screw to lock the tab in place. Now fully tighten the camera screw in Step #1.



2. Take the hex wrench and loosen the cap screw, in the strap tab, approximately 5-6 turns (there is no need to completely remove the screw).



4. Rotate the strap tab anchor into the storage position shown in photo and retighten the tab screw. This will allow you to store the anchor on the L-bracket when the tab is not being used. **When reinstalling the strap tab anchor, refer back to #2 and #3 on this sheet.**