



- a L-Bracket
- b Camera Strap Connector
- c Allen Screw
- d $\frac{5}{32}$ " Allen Wrench (large)
- e $\frac{1}{8}$ " Allen Wrench (small)



1. Attach **L-BRACKET** loosely to the bottom of the camera with $\frac{5}{32}$ " **ALLEN WRENCH** (provided).



2. Slide **L-BRACKET** to the right.



3. Insert **CAMERA STRAP CONNECTOR** into the top of the **L-BRACKET**.



4. Insert the **ALLEN SCREW** through the **CAMERA STRAP CONNECTOR** and into the top of the **L-BRACKET**. Tighten using the $\frac{1}{8}$ " **ALLEN WRENCH** (provided).



5. Tighten bottom mounting screw on the **L-BRACKET** WITH the $\frac{5}{32}$ " **ALLEN WRENCH** (provided).



www.kirkphoto.com
 800.626.5074 • 260.665.3670
 333 Hoosier Drive,
 Angola, IN 46703-9336