

How to Orient the Quick Release on the MPA-2R



1. To rotate the quick release on the monopod head, simply loosen the rotation knob **completely** (Figure A)
(please note: when loosening the knob, loosen until it stops)
This is very important. If you do not loosen all the way, it could cause internal damage.

2. When the knob is loosened, the quick release will rotate 360 degrees with positive locking positions every 90 degrees as shown in photo 2.

When you decide on your desired 90 degree position, fully tighten the rotation knob (Figure A)

If it is not locked in a 90 degree position, this could cause internal damage to the monopod head.

